

FUSES & HOLDERS



Low Profile Mini Fuse

LP03 - 3A	LP15 - 15A
LP05 - 5A	LP20 - 20A
LP07 - 7.5A	LP25 - 25A
LP10 - 10A	LP30 - 30A

10 Per Pack



Mini Blade Fuse

FLA03 - 3A	FLA15 - 15A
FLA05 - 5A	FLA20 - 20A
FLA7 - 7.5A	FLA25 - 25A
FLA10 - 10A	FLA30 - 30A

50 Per Pack



Mini Blade Fuse

0-371-56 - 5A
0-377-59 - 7.5A
0-377-61 - 10A
0-377-66 - 15A

10 Per Pack



Blade Fuse

FB03 - 3A	FB20 - 20A
FB05 - 5A	FB25 - 25A
FB07 - 7.5A	FB30 - 30A
FB10 - 10A	
FB15 - 15A	

50 Per Pack



LED Blade Fuse

LED glow when fuse is blown

FBL02 - 2A	FBL15 - 15A
FBL03 - 3A	FBL20 - 20A
FBL05 - 5A	FBL25 - 25A
FBL07 - 7.5A	FBL30 - 30A
FBL10 - 10A	

10 Per Pack



Maxi Blade Fuse

0-377-20 - 20A	0-377-60 - 60A
0-377-30 - 30A	0-377-70 - 70A
0-377-40 - 40A	0-377-80 - 80A
0-377-50 - 50A	0-377-10 - 100A

2 Per Pack



Glass Fuse - 30mm

FG02 - 2A	FG25 - 25A
FG05 - 5A	FG30 - 30A
FG10 -10A	FG35 - 35A
FG15 -15A	FG50 - 50A

50 Per Pack



Radio Fuse - 20mm

FGR01 - 1A	FGR05 - 5A
FGR02 - 2A	FGR10 -10A

50 Per Pack



Cermic/continental Fuse

FC05 - 5A	FC16 - 16A
FC08 - 8A	FC25 - 25A

50 Per Pack



Circuit Breaker Blade Fuses

12/24V

6 - GREEN -	SCB06
8 - BROWN -	SCB08
10 - RED -	SCB10
15 - BLUE -	SCB15
20 - YELLOW -	SCB20
25 - WHITE -	SCB25
30 - LT GREEN -	SCB30

1 Per Pack



Panel Mount Manual Reset Circuit Breaker

Thermal bimetallic with manual re-set. For panel mounting in 12mm diameter hole.

0-388-20 - 20A	0-388-60 - 60A
0-388-30 - 30A	0-388-70 - 70A
0-388-40 - 40A	
0-388-50 - 50A	


1 Per Pack



Strip Fuse

0-378-30 - 30A	0-378-60 - 60A
0-378-40 - 40A	0-378-80 - 80A
0-378-50 - 50A	0-378-10 - 100A

10 Per Pack



Midi Fuse

MD30 - 30A
 MD40 - 40A
 MD50 - 50A
 MD60 - 60A
 MD70 - 70A

MD80 - 80A
 MD100 - 100A
 MD125 - 125A
 MD200 - 200A

1 Per Pack



Mega Fuse

MF100 - 100A
 MF125 - 125A
 MF150 - 150A
 MF175 - 175A
 MF200 - 200A
 MF225 - 225A

MF250 - 250A
 MF300 - 300A
 MF350 - 350A
 MF400 - 400A
 MF450 - 450A
 MF500 - 500A

1 Per Pack



Pal Male Fuses

Short Leg

0-379-64 40A
 0-379-65 50A
 0-379-66 60A
 0-379-68 80A
 0-379-70 100A
 0-379-72 120A

Long Leg

0-379-75 50A
 0-379-78 80A
 0-379-80 100A

1 Per Pack



0-379-53 30A
 0-379-55 50A
 0-379-56 60A

0-379-58 80A
 0-379-60 100A
 0-379-62 120A

1 Per Pack



Pal Female Fuse

0-379-02 - 20A
 0-379-03 - 30A
 0-379-04 - 40A

0-379-05 - 50A
 0-379-06 - 60A

1 Per Pack



0-379-13- 30A
 0-379-14 - 40A

1 Per Pack



0-379-25 - 25A
 0-379-30 - 30A
 0-379-44 - 45A

0-379-46 - 65A
 0-379-47 - 75A

1 Per Pack

FUSE HOLDERS



In-line Blade Holder -

10 Or 100 Per Pack
FH220



In-line Blade Holder
Splashproof -

1 Per Pack
FH242



In-line Blade Holder -
Holder -
Plastic Cover -
Fixing Plate -

10 Or 100 Per Pack
FH220
FH210C
FH210P



Blade Fuse Holders

FH435 - 20Amp, with Lid,
FH445 - 30Amp, with Lid,
FH440 - 30Amp, with Lid,

10 Or 100 Per Pack
10 Or 100 Per Pack
10 Or 100 Per Pack

Mini Blade Fuse Holder

FH595, - 30Amp, with Lid,

10 Or 100 Per Pack

Blade Fuse Boxes

Fbb4t - 4 Way Side Entry
Fbb4u - 4 Way Underside Entry
Fbb6t - 6 Way Side Entry
Fbb6u - 6 Way Underside Entry
Fbb8t - 8 Way Side Entry
Fbb8u - 8 Way Underside Entry
K332 - 12 Way Side Entry

Individually packed.



Led Blade Fuse Holder

For Standard Blade Fuse
Led Illuminates When Fuse Is Blown

1 Per Pack

4 WAY - FBB4L
6 WAY - FBB6L
10 WAY - FBB10L





Blade Fuse Holder
Positive distribution bus
100A per block
30A per circuit

1 Per Pack
5033



Maxi Blade Fuse Holder
Splashproof

1 Per Pack
FH602



Maxi Blade Fuse Holder
With 2 sizes of terminal

1 Per Pack
0-377-00



Inline Glass Fuse Holder
30mm 17Amp

10 Per Pack
FH140



Midi/strip Fuse Holder
2 X 5mm Bolts
Max Cable Size 16mm²

1 Or 10 Per Pack
FH560



Mega Fuse Holder
2 X 8mm Bolts
Can Be Clipped Together To
Form A Fuse Block

1 Or 10 Per Pack
FH569



Add A Circuit Fuse Holder
Standard Blade Fuse -
Mini Blade Fuse -

2 Per Pack
FH450
FH597



Blade Fuse Tester/Extractor
When the three pins are placed on
the exposed metal part of the
blade fuse the green indicator light
will glow if the fuse has not blown.

Individually packed.
FBT